

First Steps

Learning by doing is most of the times the best option. So, try out the demos on

<https://www.nora-imaging.org/>

to get an initial experience. Note that there is also a non-web version of the viewer (packed in electron) to allow local non-internet usage of the viewer (download also [here](#))

NORA's desktop

NORA's basic working screen is like that: 

NORA's imaging data is organized in projects. Each project contains a set of subjects/studies, which appear in the left table of the desktop.

Loading data for viewing happens in most of the cases per **drag&drop**. You can drag images from the subject/study table (see [here](#) for more about the table) into the viewports on the right. By **double-clicking** a file its content is loaded and placed into next available viewport. You can also **drag&drop files from your local computer** into the viewports for visualization (note that the data is not uploaded, it stays on your local machine).

Depending on the file type different drop options appear in the viewports. For example, if you want to overlay one image onto another just drop on "drop as overlay". Hence, each viewport can contain multiple items: a background, overlays, masks, fibers and surfaces (in 3D) etc.. Corresponding to each item a **viewbar** appears in the upper right corner of the viewport. The viewbar controls the appearance of the associated object/contrast. Most properties (colormapping, outlines, etc.) are set for all instances of the object in all viewports. If you want to choose the same object to have different appearance properties in different viewports use the shift key while selecting the property.

The viewbar of the "background" image is organized as follows



Central Toolbar

image 1601633873571.png

Viewports and Viewer Layout

To control the layout of the viewports use the layout selector located at the central toolbar. Note that for the horizontal viewports at the bottom a mosaic view is default.

image 1601633656873.png

Mouse

Mouse wheel	change slice
Ctrl + Mouse wheel	zoom
Right mouse button (hold down)	pan
Left mouse button click	change position of crosshair (world position)
Middle mouse button	Change windowing
Ctrl + Left Mouse button hold	Reformatting MPR (rotation/translation) , see Navigation Tool

Keyboard Shortcuts

1-6,0	shortcuts to standard CT windowings
Space	toggle ROI edit, see ROI tool
s	open settings window
x,y	decrease/increase scroll speed
arrow up/down	change subject (when using autoloader)
(shift) Ctrl-Z	Undo/Redo ROI drawing

Revision #17

Created 16 September 2020 18:50:10 by root

Updated 12 October 2020 12:17:56 by reiser tm